

RP100 Seal Replacement Information

- 1) Remove the RP100 from system
- 2) If fitted, remove the handwheel / motor assembly, this is held on to the body via cap head screws.
- 3) Remove Index Dial (3)
- 4) Remove the Bearing Clamp Ring (1)
- 5) Lift off Rotating Flange (6)
- 6) Remove seals and spacers
- 7) Clean out with Isopropanol
- 8) Wipe over new seals with isopropanol to remove lose surface
- 9) Fit seals and spacers
- 10) Fit Rotating Flange and clamp ring.
- 11) When fully assembled, the turning torque should be between 8Nm & 18Nm.
- 12) If possible, test on a leak checker with the interspaces pumped







